

Spare parts list JK35T590
Drawing 118646

Pos Ref Pos Ref No.	Detalj Part Artikel Référence No.	Benämning	Description	Bezeichnung	Designation	Antal Qty	Ann. Notes
A	143049	O-ring sats	O-ring Kit	Oringsatz	Jeu d'Orings		
B	143050	Reparationsats	Repair kit	Reparaturatz	Jeu de rechange		
1	946657	Skruv	Screw	Schraube	Vis	4	
2	179084	Topplöck	Cap	Platte	Chapeau	1	
3	148034	Packning	Gasket	Dichtung	Garniture inférieure	1	
4	149044	Kompressionsbricka	Compression Washer	Druckscheibe	Rondelle de compr.	1	
5	150337	Lock for cyl.foder	Cylinder cap	Zylinderkappe	Chapeau de cylindre	1	
6	148040	Tättningsring	Seal	Ring	Garniture	1	
7	972110	Glidring	Glide ring	Gleitring	Bague	2	
8	972119	O-ring	O-ring	O-ring	Joint torique	2	
9	191143	Kolv	Piston	Kolben	Piston	1	
10	145117	Drivhållarpinne	Driver pin	Stift	Axe d'enfonceur	1	
11	149088	Kolvdämpare övre	Upper bumper	Bodenplatte	Butée	1	
12	164098	Drivare	Driver blade	Stößelblech	Lame d'enfonceur	1	
13	134243	Kolv kompl. m. driv.	Piston with driver	Kolben kpl	Piston enf. compl.	1	
14	190159	Cylinderfoder	Cylinder	Zylinder	Cylindre	1	
15	972115	O-ring	O-ring	O-ring	Joint torique	1	
16	148035	Tättn.ring backventil	Seal for back valve	Ventilring	Garniture de valve	1	
17	149087	Kolvdämpare nedre	Lower bumper	Bodenplatte	Butée	1	
18	150295	Hylsa	Cage	Hülse	Cage	1	
19	972118	O-ring	O-ring	O-ring	Joint torique	1	
20	972117	"	"	"	"	1	
21	150294	Mellanring	Cylinder ring	Zylinderring	Bague centrale	1	
22	972116	O-ring	O-ring	O-ring	Joint torique	1	
23	972114	"	"	"	"	2	
24	147093	Bottenbricka	Bottom washer	Scheibe	Rondelle	1	
25	148033	Packning	Gasket	Dichtung	Garniture inférieure	1	
26	972058	O-ring	O-ring	O-ring	Joint torique	1	
27	179058	Anslutningslock	Cap	Abschlussdeck	Couvercle	1	
28	946512	Skruv	Screw	Schraube	Vis	2	
29	971003	Ljuddämpare	Sound absorber	Schalldämpfer	Silencieux	1	
30	987026	Insticksnippel	Nippel	Stecknippel	Raccord	1	
31	946699	Skruv	Screw	Schraube	Vis	4	
32	162694	Främre drivarstyming	Front nozzle plate	Abdeckplatte	Plaque avant	1	
33	162692	Bakre drivarstyming	Rear nozzle plate	Führungsplatte	Plaque arrière	1	
34	946511	Skruv	Screw	Schraube	Vis	2	
35	165040	Avtryckare	Trigger	Ventilhebel	D'etente	1	
36	945039	Spännstift	Tension pin	Stift	Goupille de tension	1	
37	162695	Dörr	Door	Vorderplatte	Porte	1	
38	946657	Skruv	Screw	Schraube	Vis	1	
39	972030	O-ring	O-ring	O-ring	Joint torique	1	
40	972039	"	"	"	"	1	
41	191084	Ventilhylsa	Valve cage	Ventilkolben	Cage de valve	1	
42	173066	Fjäder	Spring	Ventilfeder	Ressort	1	
43	972121	O-ring	O-ring	O-ring	Joint torique	2	
44	191153	Ventilspindel	Valve stem	Ventilkolben	Cage de valve	1	
45	146102	Mutter	Nut	Mutter	Ecrou	1	
46	174057	Frammatarfjäder	Feeder spring	Zugfeder	Ressort de poussoir	1	
47	161247	Frammatare	Pusher	Kolben	Poussoir	1	
48	150291	Fjädercentrum	Spring center	Federrolle	Ressort central	1	
49	946702	Skruv	Screw	Schraube	Vis	1	
50	156946	Fjäderhus	Springhouse	Federhaus	Ressort de chargement	1	
51	145134	Axel för fjäderrulle	Schaft for springroller	Stift	Aigville	1	
52	174058	Fjäder	Spring	Feder	Ressort	1	
53	135145	Fäste laddn.lucka	Cover holder	Endabdeckung	Support	1	
54	134194	Laddningslucka	Cover	Abdeckung	Porte de chargement	1	
55	134244	Täckplåt	Staple shield	Abdeckschiene	Protecteur en tôle	1	
56	946663	Skruv	Screw	Schraube	Vis	1	
57	160124	Frammatarstopp	Pusherstop	Klobenstopper	Arret de poussoir	1	
58	173052	Låsfjäder	Lock spring	Druckfeder	Ressort de blocage	1	
59	160123	Låskolv	Lock piston	Bolzen	Piston de blocage	1	
60	150311	Spärhylsa	Lock cage	Verschlusshülse	Cage de blocage	1	
61	162687	Klanmerbana	Rail	Klammerträger	Rail	1	
62	146202	Plattjärsmutter	Nut	Mutter	Ecrou	1	
63	946697	Skruv	Screw	Schraube	Vis	3	
64	146201	Plattjärsmutter	Nut	Mutter	Ecrou	1	
66	150325	Mellanlägg 6 mm	Distance plate 6 mm	Distanzplatte 6 mm	Intermédiaire 6 mm	1	
67	150326	" 3 mm	" 3 mm	" 3 mm	" 3 mm	1	
68	946516	Skruv	Screw	Schraube	Vis	4	
69	146213	Plattjärsmutter	Nut	Mutter	Ecrou	1	
70	176018	Fäste för tunga	Bracket	Füma	Supportbras dénclume	1	
71	158248	Tunga	Tongue	Heftzunge	Bras dénclume	1	
72	146212	Plattjärsmutter	Nut	Mutter	Ecrou	1	
73	946700	Skruv	Screw	Schraube	Vis	1	
74	146211	Mutter	Nut	Mutter	Ecrou	1	
75	946699	Skruv	Screw	Schraube	Vis	4	
76	946538	"	"	"	"	1	
77	946714	"	"	"	"	1	
78	132296	Klanmerbana kompl	Rail	Klammerträger	Rail	1	
79	110174	Varningskyld	Warning label	Sicherheitsschild	Plaque de sign	1	Swedish
	110175	"	"	"	"	1	English
	942002	Sexkantsnyckel	Hexagon spanner	Winkelschrauben dreher	Clef pour vis à six pans creux	1	