










# AC01



| ITEM | DESCRIPTION             | PART NUMBER | Q'TY |
|------|-------------------------|-------------|------|
| 1    | Set Screw               | AC01001     | 1    |
| 3    | Shakeproof lock Washer  | AC01003     | 7    |
| 4    | Air Deflector           | AC01004     | 1    |
| 5    | Rear Valve Seat         | AC01005     | 1    |
| 6    | O-Ring                  | AC01006     | 2    |
| 7    | Throttle Spring         | AC01007     | 1    |
| 8    | Throttle Spring Locator | AC01008     | 1    |
| 9    | Throttle Valve Screw    | AC01009     | 2    |
| 10   | Valve Screw Washer      | AC01010     | 2    |
| 11   | O-Ring Support          | AC01011     | 4    |
| 12   | O-Ring                  | AC01012     | 5    |
| 13   | O-Ring Center Support   | AC01013     | 2    |
| 14   | Throttle Valve Spacer   | AC01014     | 1    |
| 16   | Front Valve Seat        | AC01016     | 1    |
| 17   | Throttle Stem           | AC01017     | 1    |
| 18   | Button Head Cap Screw   | AC01018     | 1    |
| 20   | Trigger Guard           | AC01020     | 1    |
| 21   | Flexloc Nut             | AC01021     | 2    |
| 23   | Stud                    | AC01023     | 2    |
| 27   | Housing                 | AC01027     | 1    |
| 28   | Set Screw               | AC01028     | 2    |
| 29   | O-Ring                  | AC01029     | 1    |
| 30   | Piston                  | AC01030     | 1    |
| 31   | Cylinder Gasket         | AC01031     | 1    |
| 32   | Piston Stop Spacer      | AC01032     | 1    |
| 35R  | Side Plate (Right)      | AC0135R     | 1    |
| 35L  | Side Plate (Left)       | AC0135L     | 1    |
| 36   | Roll Pin                | AC01036     | 3    |
| 37   | Trigger                 | AC01037     | 1    |
| 39   | Socket Head Cap Screw   | AC01039     | 4    |
| 40   | Upper Jaw               | AC01040     | 1    |
| 41   | Jaw Bushing             | AC01041     | 2    |
| 43   | Latch Pin Clip          | AC01043     | 1    |
| 44   | Latch Spring            | AC01044     | 1    |
| 45   | Latch                   | AC01045     | 1    |
| 46   | Roller                  | AC01046     | 4    |
| 47   | Feeder Blade            | AC01047     | 1    |
| 48   | Piston Rod              | AC01048     | 1    |
| 49   | Roller Pin              | AC01049     | 1    |
| 50   | Lower Jaw               | AC01050     | 1    |
| 51   | Feeder Arm              | AC01051     | 1    |
| 56   | Washer                  | AC01056     | 2    |
| 57   | Nut                     | AC01057     | 4    |
| 58   | Screw                   | AC01058     | 2    |
| 59   | Inlet Bushing           | AC01059     | 1    |
| 64   | Socket Head Cap Screw   | AC01064     | 1    |
| 67   | Nut                     | AC01067     | 1    |
| 68   | Pusher                  | AC01068     | 1    |
| 69   | Extruded Rivet          | AC01069     | 1    |
| 70   | Pusher Spring           | AC01070     | 1    |
| 71   | Button Head Screw       | AC01071     | 1    |
| 73   | Magazine Body           | AC01073     | 1    |
| 74   | Jaw Bolt                | AC01074     | 2    |
| 75   | Magazine Spring         | AC01075     | 1    |
| 76   | Magazine Shoe           | AC01076     | 1    |
| 77   | Roll Pin                | AC01077     | 1    |
| 78   | Magazine Shim           | AC01078     | 1    |
| 78A  | Magazine Shim           | AC0178A     | 1    |
| 79   | Washer                  | AC01079     | 2    |
| 86   | Plate Screw             | AC01086     | 1    |
| 89   | Flexloc Nut             | AC01089     | 3    |
| 207  | Feeder Guid Rail        | AC01207     | 1    |