


95-105 IN LBS.  
OF TORQUE.  
(109-121 CM-KG)

125-140 IN LBS.  
OF TORQUE.  
(144-161 CM-KG)  
4 PLACES



## Parts List for F28WW Type 0

| Item Number | Part Number | Description          | Qty Required |
|-------------|-------------|----------------------|--------------|
| 1           | MSF6100-25  | SCREW-SFHCS-M6X1.00X | 1            |
| 2           | 163859      | BUSHING-EXHAUST DEFL | 1            |
| 3           | 108562      | SCREW-TRIGGER PIVOT  | 1            |
| 3           | 163818      | DEFLECTOR-EXHAUST    | 1            |
| 4           | 163830      | PLATE-CAP            | 1            |
| 5           | MSC6100-30  | SCREW-SHCS-M6X1.00X3 | 4            |
| 6           | 163827      | PLATE-WEAR           | 1            |
| 7           | 149819      | WEAR GUIDE           | 1            |
| 8           | 163848      | FRAME CAP-MACHINING  | 1            |
| 9           | 105814      | O-RING-1.929X.098    | 1            |
| 10          | 163820      | BUMPER-HEAD VALVE    | 1            |
| 11          | 163844      | SPRING-HEAD VALVE    | 1            |
| 12          | 163822      | O-RING-2.487X.103XNB | 2            |
| 13          | 163821      | LOWER BODY-HEAD VALV | 1            |
| 14          | 163823      | SEAL-HEAD VALVE      | 1            |
| 15          | 163845      | SEAL-FRAME/CAP       | 1            |
| 16          | 851606-S    | O-RING-1.850X.210    | 1            |
| 17          | 163922      | ASSEMBLY-PISTON/DRIV | 1            |
| 18          | 163824      | SLEEVE-CYLINDER      | 1            |
| 19          | 175520      | SEAL-CHECK           | 1            |
| 20          | 163855      | RING-CYLINDER SLEEVE | 1            |
| 21          | 108718      | O-RING-3.484X.139    | 1            |
| 22          | 89673       | O-RING               | 1            |
| 23          | 163856      | SEAL-END CAP         | 1            |
| 24          | 163843      | END CAP-PAINT        | 1            |
| 25          | T50118      | WASHER-PLAIN         | 1            |
| 26          | MSC5080-20  | SCREW-SOC HD. CAP M5 | 4            |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for F28WW Type 0

| Item Number | Part Number | Description          | Qty Required |
|-------------|-------------|----------------------|--------------|
| 28          | 171432      | LABEL-MAGNESIUM      | 1            |
| 29          | 171127      | FRAME-OVERMOLD       | 1            |
| 30          | 107231      | BUMPER-DRIVE         | 1            |
| 31          | 166781      | SPRING-UPPER TRIP    | 1            |
| 32          | 163899      | ARM-UPPER CONTACT    | 1            |
| 33          | MSC4070-16  | SCREW-SHCS-M4X0.7X16 | 1            |
| 35          | 163927      | NOSE-F28WW           | 1            |
| 36          | 166772      | SPRING-CONTACT ARM   | 1            |
| 37          | 108224      | CASTING-HOUSING CONT | 1            |
| 38          | 108227      | ARM-LOWER CONTACT    | 1            |
| 39          | 121072      | ASSEMBLY-TRIP FOOT   | 1            |
| 40          | 115230      | SPRING-HOUSING       | 1            |
| 41          | 166777      | CASTING-PLUNGER      | 1            |
| 42          | MSC8125-30  | SCREW-SHCS M8X30     | 4            |
| 45          | 121070      | FOOT-TRIP            | 1            |
| 46          | 121071      | CLIP-TRIP FOOT       | 1            |
| 47          | 163883      | GUIDE-ARM            | 1            |
| 48          | SEQ7        | KIT-SEQUENTIAL TRIP  | 1            |
| 49          | CNTK5       | KIT-CONTACT TRIP CON | 1            |
| 50          | 100387      | SPRING-COMPRESSION   | 1            |
| 51          | TVA6        | KIT-TRIGGER VALVE    | 1            |
| 53          | 108562      | SCREW-TRIGGER PIVOT  | 2            |
| 54          | MHE3050-100 | NUT-NYLON M3X.50     | 2            |
| 55          | 100298      | PIN-SPIRAL M3X30     | 1            |
| 56          | MPP030020   | PIN-SPIRAL M3X20MM   | 1            |
| 57          | N70143      | BUSHING-RUBBER       | 1            |
| 58          | MPW6.2      | WASHER.SPECIAL       | 1            |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for F28WW Type 0

| Item Number | Part Number | Description          | Qty Required |
|-------------|-------------|----------------------|--------------|
| 59          | 158612      | LABEL-WARNING        | 1            |
| 60          | 112769      | LABEL-N88WW FASTENER | 1            |
| 61          | MSC5080-6   | SCREW-SHCS-M5X0.80X6 | 3            |
| 62          | 188578      | TEE NUT              | 1            |
| 63          | 159718      | LINER-NAIL GUIDE-N88 | 1            |
| 64          | 166797      | O-RING-.056X.060 NBR | 1            |
| 65          | 104981      | LABEL-WARNING        | 1            |
| 66          | 100261      | SCREW                | 1            |
| 67          | 121472      | SPACER-PUSHER LATCH  | 1            |
| 68          | 166784      | MAGAZINE-PAD PRINT-F | 1            |
| 69          | 166778      | LATCH-PUSHER         | 1            |
| 70          | 120927      | LABEL-SENSOR SMALL ( | 1            |
| 71          | 116563      | CAP END-MAGAZINE     | 1            |
| 72          | 116965      | WASHER-PLAIN M5      | 3            |
| 73          | 120878      | SPRING- PUSHER LATCH | 1            |
| 74          | MPW4        | WASHER-PWN-M4        | 1            |
| 75          | MHE4070-100 | ELASTIC STOP NUT-M4  | 1            |
| 76          | 121407      | PIN-SPECIAL          | 1            |
| 77          | 100209      | SCREW                | 2            |
| 78          | 158767      | PUSHER-WW            | 1            |
| 79          | 115143      | SPRING-CONSTANT FORC | 1            |
| 80          | 120945      | HANDLE-PUSHER        | 1            |
| 81          | 163882      | GUIDE-DRIVER         | 1            |
| 82          | 112630      | SHIELD-DUST          | 1            |
| 83          | 112631      | SPRING-CLIP          | 1            |
| 84          | 163858      | PLUG-EXHAUST         | 1            |
| 85          | MHE6100-100 | NUT-ESN M6X1         | 1            |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for F28WW Type 0

| Item Number | Part Number | Description          | Qty Required |
|-------------|-------------|----------------------|--------------|
| 88          | 171354      | ASSEMBLY-UTILITY HOO | 1            |
| 89          | 163903      | BUSHING-TRIP COVER   | 1            |
| 90          | 171338      | COVER-TRIP           | 1            |
| 91          | MSB6100-40  | SCREW-SBHCS-M6X1.00X | 1            |
| 92          | 171342      | WASHER-UTILITY HOOK  | 1            |
| 93          | 171339      | HOOK-UTILITY         | 1            |
| 94          | 171340      | MOUNT-UTILITY HOOK   | 1            |
| 95          | 171341      | SPRING-UTILITY HOOK  | 1            |
| 96          | UB3811.2    | PIN- SPIROL - 5/32X3 | 1            |
| 800         | 100653      | LUBE (2CC)           | 1            |
| 800         | 100679      | LUBE (1LB.CAN)       | 1            |
| 876         | N89ORK      | O-RING KIT           | 1            |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.