

AD02

PARTS DETAILS

1. Set Screw
3. Shakeproof lock Washer
4. Air Deflector
5. Rear Valve Seat
6. O-Ring
7. Throttle Spring
8. Throttle Spring Locator
9. Throttle Valve Screw
10. Valve Screw Washer
11. O-Ring Support
12. O-Ring
13. O-Ring Center Support
14. Throttle Valve Spacer
15. Piston Rod
16. Front Valve Seat
17. Throttle Stem
18. Button Head Cap Screw
23. Stud
24. Cylinder Housing
27. Carriage Assembly
28. Set Screw
29. O-Ring
30. Piston
31. Cylinder Gasket
32. Piston Stop Spacer (Assy. Only)
33. Right Arm Link
34. Clevis
35. Set Screw
36. Roll Pin
37. Left Arm Link
38. Roll Pin
39. Left Jaw
40. Slide
41. Right Jaw
42. Socket Head Cap Screw
43. Socket Head Cap Screw
44. Roll Pin
45. Teeth (Straight)
46. Stop Pin
47. Trigger Guard Bracket
48. Roll Pin
49. Trigger
50. Trigger Guard
51. Pusher Assembly
52. Lock Washer
53. Socket Head Cap Screw
54. Magazine Assembly
59. Inlet Bushing
89. Flexloc Nut
200. Trigger Guard Bracket Assy.

